


4-STEP & FULL-FIELD TEST BASIC INFORMATION

THE FOUR-STEP TEST IS DONE WITH EVERYTHING PLUGGED IN



THE FULL-FIELD TEST IS DONE AT THE REGULATOR 4-WIRE CONNECTOR WITH IT DISCONNECTED FROM THE REGULATOR

NO VOLTAGE TESTS ARE DONE AT THE DISCONNECTED REGULATOR AT ANY TIME

