



## PX-2, PX-4G-5 & PX-5 FAN SPACER APPLICATION LIST PENNTEX ALTERNATORS AND THE CORRECT FAN SPACER FOR THAT MODEL

TWO FAN SPACER PART NUMBERS ARE USED:

PX-1058 SILVER: .133" THICK


PX-1273 GOLD: .046" THICK

- PX-2P-5: PX-1058 SILVER
- PX-2P2D-5: PX-1058 SILVER
- PX-2P2-5: PX-1058 SILVER
- PX-2R-5: PX-1273 GOLD
- PX-2R-5A: PX-1273 GOLD
- PX-2R-5T: PX-1273 GOLD
- PX-2RL-5T: PX-1273 GOLD
- PX-2T-5: PX-1273 GOLD
- PX-2TF-5: PX-1273 GOLD
- PX-2TF-6.0L: PX-1273 GOLD

- PX-4G-5 (S#049914736 & up) &  
 PX-5GD200/230 & 250:  
 PX-1273 GOLD (TWO OF THEM)

- PX-5P/PX-5PD-200/230/250: PX-1058 SILVER
- PX-5P2/PX-5P2D-200/230/250: PX-1058 SILVER
- PX-5R/PX-5RD-200/230: PX-1273 GOLD
- PX-5R/PX-5RD-250: PX-1273 GOLD
- PX-5T/PX-5TD-200/230: PX-1273 GOLD
- PX-5T/PX-5TD-250: PX-1273 GOLD
- PX-5TD-6-200/230: PX-1058 SILVER
- PX-5TD-6-250: PX-1058 SILVER
- PX-5TD-6C-200/230: PX-1273 GOLD
- PX-5TD-6C-250: PX-1273 GOLD
- PX-5TD-12-200/230: PX-1273 GOLD
- PX-5TD-12-250: PX-1273 GOLD
- PX-5TFD-200/230: PX-1273 GOLD
- PX-5TFD-250: PX-1273 GOLD

### EXAMPLES OF FAN SPACERS



ON THESE MODELS THE SPACER ALWAYS GOES BETWEEN THE FRONT BEARING AND THE FAN. USING A PLAIN WASHER OR THE WRONG SPACER WILL CAUSE BELT ALIGNMENT PROBLEMS.

NOTE THAT SOME PX-5TD MODELS USE DIFFERENT SPACERS DEPENDING ON THE APPLICATION. BE SURE THE SPACER YOU USE IS THE RIGHT ONE.

## PERFORMANCE, ENDURANCE AND SATISFACTION



**Manufacturers of  
 High Efficiency Alternators and  
 Mobile Electronic Devices.**

**Corporate:**  
 202 Plaza Drive  
 Manchester, PA 17345  
 Ph: 717/266-8762  
 Fax: 717/266-7803

[www.penntexusa.com](http://www.penntexusa.com)  
 Email: [sales@penntexusa.com](mailto:sales@penntexusa.com)

**Manufacturing:**  
 7620 Flagstone Drive  
 Fort Worth, TX 76118  
 Ph: 817/590-2818  
 Toll Free: 877/590-7366  
 Fax: 817/590-0505

